






Cartridge Change Instructions

QL2 Head
Without Shut-Off Valve

CARTRIDGE REMOVAL

1. Shut off water and relieve line pressure.
2. Hold head firmly. Turn cartridge to left 1/4 turn until rotation stops.






Cartridge Change Instructions

QL3/QC7 Head
With Shut-Off Valve

CARTRIDGE REMOVAL

1. Shut off water and relieve line pressure. Fully lift built-in shut-off valve handle until it stops.
2. Hold head firmly. Turn cartridge to left 1/4 turn until rotation stops.






EVERPURE[®]

CARTRIDGE REMOVAL AND REPLACEMENT

1. Shut off water to system. Disconnect outlet tubing or open an outlet line valve to relieve pressure.
2. Hold head firmly. Turn cartridge to left 1/4 turn until rotation stops.







Cartridge Change Instructions

L