
AUTOSET FEATURE

The AutoSet feature is a time clock override that allows the heat pump to start and stop a remote filter pump to ensure it can properly sense and maintain water temperature.

MOUNTING THE AUTOSET CONTACTOR (cont.)

4. Locate the contactor mounting location in the bottom right of the wiring



1620 HAWKINS AVE., SANFORD, NC 27330 (919) 566-8000
10951 WEST LOS ANGELES AVE., MERRICK PARK, CA 93021 (805) 553-5000

All other Pentair trademarks and registered trademarks of Pentair, Inc. and its subsidiaries are hereby acknowledged.

© 2022 Pentair, Inc. All rights reserved. WWW.PENTAIR.COM



P/N 476462 REV. A 9/26/22